

- **Suggestions for a safe journey**

Print the second Page

- **Suggerimenti per un viaggio sereno**

Stampa la terza pagina



MAKE A PEACEFUL JOURNEY WITH ROOF TOP TENT

With these suggestions, your journey will be peaceful.
In fact, all Vivishare rentals, with this information supplied
by the renters to the customers,
they have always concluded with satisfaction.

TO OPEN THE TENT PAY ATTENTION TO UNLOCK AT FRONT AND REAR THE SAFETY LOCKS.

If you try to open without unlocking, you could break the mechanism for lift.

OPENING

The tent must be opened by turning the handle-crank clockwise.

ALWAYS REMOVE THE HANDLE CRANK AFTER YOU HAVE USED IT AND TAKE IT IN THE CAR.

If you start with the handle crank inserted you could lose it.

PAY ATTENTION TO TRANSVERSAL BARS ANTI CAMPER IN THE PARKING

Your car isn't as high as before but is taller. Remember that you have the TENT ON THE ROOF of the car.

DO NOT CLOSE THE CURTAIN IF THE CANVAS IS WET AND BE CAREFUL WHEN IS RAINING

If you close the curtain with a wet cloth, the mattress could get wet.

A couple of hours in the air is enough because the towel dries.

When it's raining, and the tent is open don't leave things, like pillows or blankets attached at the canvas. They do like a sponge: they absorb the water inside.

DO NOT CLEAN THE CANVAS WITH SOLVENTS OR DEGREASERS

The cloth can only be cleaned with lukewarm water,
Marseille soap and a mild NON-abrasive cloth.

DO NOT LOAD ANYTHING ABOVE THE TENT SHELL

Only on predisposed tents, for example, the Adventure of Autohome, it is possible to fix objects above the tent

DRIVE SAFELY! Good journey!



FAI UN VIAGGIO SERENO

- **PRIMA DI APRIRE LA TENDA, ASSICURATI DI AVER SGANCIATO DAVANTI E DIETRO, LE CERNIERE DI SICUREZZA**

Se non sganci prima le cerniere potresti rompere i meccanismi di sollevamento interni.

- **APERTURA:**

La tenda va aperta girando la manovella in senso orario, e va chiusa girando in senso antiorario.

- **TOGLI SEMPRE LA MANOVELLA DOPO AVERLA USATA E RIPONILA NELL'AUTO.**

Se riparti con la manovella inserita potresti perderla.

- **FAI ATTENZIONE ALLE BARRE TRASVERSALI ANTI CAMPER NEI PARCHEGGI**

La tua auto non è alta come prima. E' più alta. Ricordati che hai la TENDA SUL TETTO dell'auto.

- **NON CHIUDERE LA TENDA SE IL TELO È BAGNATO**

Se chiudi la tenda con il telo bagnato, il materasso potrebbe bagnarsi. Sono sufficienti un paio d'ore all'aria perché il telo si asciughi.

- **NON PULIRE IL TELO CON SOLVENTI O SGRASSATORI**

- **Il telo può essere pulito solo con acqua tiepida, sapone di marsiglia e un panno delicato NON abrasivo.**

•

- **NON CARICARE NIENTE SOPRA IL GUSCIO DELLA TENDA**

- **Soltanto sulle tende predisposte, per esempio l'Adventure della Autohome, è possibile fissare oggetti sopra la tenda.**

- **DAVANTI E DIETRO IL TELO VA AVVOLTO IN UNA TASCA NEL GUSCIO INFERIORE**

- **Nel fase di chiusura poni attenzione ad infilare il telo nella sua tasca sul guscio inferiore. Eviterai che il telo vada a toccare i meccanismi di apertura e chiusura, che potrebbero sporcare il telo**

- **GUIDA CON PRUDENZA**

BUON VIAGGIO !